

# DATSS Operator Panel

## Quick Start Guide

.....

The default Ethernet setup is shown here. The Wireless Access Point is not required for a Bluetooth connection.

.....



### ETHERNET HARDWARE SETUP

1. Connect an Ethernet cable from the Wireless Access Point to the PoE adapter.
2. Connect another Ethernet cable from the PoE adapter to your computer.
3. Plug the PoE adapter into an electrical outlet.

### BLUETOOTH HARDWARE SETUP

If your computer does not support Bluetooth, simply plug the provided Bluetooth dongle into a USB port on your computer.



Note: The Windows 10 Bluetooth driver is included on the USB drive.



### Simrad

Kongsberg Maritime AS  
Strandpromenaden 50  
P.O.Box 111  
N-3191 Horten, Norway

Telephone: +47 33 03 40 00  
Telefax: +47 33 04 29 87  
[www.simrad.com](http://www.simrad.com)  
[simrad.sales@simrad.com](mailto:simrad.sales@simrad.com)

# SIMRAD

# DATSS Operator Panel

## Quick Start Guide

### ETHERNET SOFTWARE SETUP



1. Make sure that the DATSS software is running.
2. Press and hold the **Power** key on the right side of the tablet to turn on the DATSS Operator Panel.

Wait for the tablet to boot up. Observe that the Remote Control App opens automatically. If the app does not open automatically, tap the Remote Control App icon on the tablet's home screen.

3. Connect the tablet to the Ethernet server.
  - a. In the **Connection Options** dialog box, tap on **Ethernet**.
  - b. Tap **Next** to dismiss the reminder.

Observe that an **IP Address** dialog box opens.

IP ADDRESS

Please enter the IP address of the server:

IP Address: 192.168.0.201

Port Number: 9000

Done


- c. Make sure that "192.168.0.201" appears in the **IP Address** field.
- d. Tap **Done**.
- e. Wait for the tablet to connect to the server.

When the Keypad page appears, you can start using the Operator Panel.

### BLUETOOTH SOFTWARE SETUP



1. Make sure that the DATSS software is running.
2. If you are using the Bluetooth dongle, install the Bluetooth driver that comes with it.
3. Pair the tablet with the computer.
  - a. Open **Settings** on the tablet.
  - b. Tap **Connections** → **Bluetooth**.
  - c. Turn on Bluetooth.
  - d. Open **Settings** on the computer.
  - e. Click **Devices** → **Bluetooth & other devices**.
  - f. Turn on Bluetooth.
  - g. On your tablet, tap on your computer name in the **Available devices** list.



- h. Tap **OK** on the tablet.
  - i. On your computer, click on the popup, then click **Yes**.
4. Connect the tablet to the Bluetooth server.
    - a. Tap on the Remote Control App icon.
    - b. In the **Connection Options** dialog box, tap on **Bluetooth**.
    - c. Tap **Next**.
    - d. If your tablet requests access to the device's location, tap **Allow**.
    - e. Tap the name of your computer, then tap **Next**.
    - f. Wait for the tablet to connect to the server.

When the Keypad page appears, you can start using the Operator Panel.

.....

You will experience the best performance using Ethernet. However, Bluetooth is available as a backup option if you are experiencing problems with the Wireless Access Point.

.....